

PrioVino Premier

Translation of Original Operating Instructions

Status: August 2018

EN



First edition January 2018 / © PrioVino GmbH

Reprint – even in extracts – only upon written
permission by PrioVino GmbH (ISO 16016).

PRIOVINO
BECAUSE TASTE MATTERS

Contents

1. **General information**
 - 1.1 Information about these operating instructions
 - 1.2 Safety warnings
 - 1.3 Limitation of liability
2. **Safety**
 - 2.1 Proper use
 - 2.2 General safety instructions
 - 2.3 Safety instructions for battery and battery charger
3. **Before use**
 - 3.1 Unpacking the device
 - 3.2 Parts and accessories included
 - 3.3 Names of working parts
 - 3.4 Correct placement of the device
 - 3.5 Checking electrical connections
 - 3.6 Charging the battery
4. **Set-up and operation**
 - 4.1 Inserting the battery
 - 4.2 Setting the desired temperature
 - 4.3 Removing the battery
 - 4.4 Mains operation
5. **Cleaning instructions**
6. **Storage**
7. **Service and maintenance**
8. **Disposal**
9. **Technical information**
10. **Declaration of conformity**

The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited.

Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design.

1. General Information

1.1 Information about these operating instructions

These are the operating instructions for the wine cooler PrioVino Premier (hereafter referred to as the device). It provides important information for the safe operation of the device and must be carefully studied by anyone who sets up, operates or cleans it. Non-compliance with the instructions laid out in this manual can lead to injuries to the user and/or damage to the product. Please keep the user manual at a safe and easily accessible location at the operation site of the device.

You can download the operating instructions from our website, where it is available at www.priovino.com/downloads also in additional languages.

Content and technical specifications are subject to change without notice.

1.2 Safety warnings



indicates warnings about situations that could lead to serious injury or constitute a fire hazard.



indicates a warning about situations that could be hazardous to the user or cause product damage.

1.3 Limitation of liability

The information, facts and figures, diagrams and technical instructions contained in these operating instructions were compiled with the utmost care in order to make the set-up, operation and cleaning of this device safe and easy. Illustrations may be exemplary.

The manufacturer assumes no liability for damage or injury caused by non-compliance with the instructions in these operating instructions as well as for any damage caused due to improper repairs, technical modifications to the device or the use of third-party spare parts.

All translations of these operating instructions were carried out by professional translators. The manufacturer assumes no liability for damage or injury caused by incorrect translations. In doubt, please refer to the original operating instructions.

2. Safety

This device complies with all statutory safety regulations. However, the improper use of the device may lead to injuries, material damage or damage to the product.

2.1 Proper use



Use the device only for the intended purpose. Improper use or non-compliance with these operating instructions can have very dangerous consequences.

2.1.1 Personnel requirements

The device may only be operated by personnel authorized, suitable, qualified, instructed and trained by the contractor therefor.

The operator is obliged to inform the operating personnel about changes to the device and to train them if necessary.

2.1.2 Predicted area of operation

The device is only intended to keep cool pre-cooled wine bottles with a diameter of not more than 9.4 cm mainly in the commercial area. The intended temperature range for the bottle is 5 °C – 20 °C.

The device may only be operated in technically flawless condition and for proper, safety-conscious and risk-conscious use while observing the operating instructions! Especially, malfunctions which pose a safety risk must be fixed right away! Proper use includes closely following the operating instructions as well as the compliance with the maintenance regulations.

The device is designed for the environmental conditions described in section "g. Technical information".

Modifications to the device need the written approval by PrioVino GmbH. A conversion of the device has to be carried out and tested prior to use by PrioVino GmbH.

2.1.3 Unauthorized area of use - foreseeable misuse

A different use or a use that exceeds the described range is considered improper. PrioVino GmbH is not liable for any resulting damages. The risk is solely borne by the operator.

The device is not designed to cool down or heat up wine bottles.

In particular, it is not allowed to misuse the device e.g. as shelf, coat stand or standing aid. It is also not allowed to introduce liquid into the bottle opening – even for cleaning purposes.



Caution

2.2 General safety instructions

- Inspect the device before use and do not switch it on if there is any visible external damage.
- Children may not be left unattended with the device or operate it.
- Injuries could result from the falling down or toppling over of the cooler or its stand.
- The device may only be operated by persons with mental, physical or sensory impairments if they have been instructed about the safe operation of the device as well as possible dangers or if they are supervised.
- If you plug your device into a mains power supply, please fasten the power cord to the cooler stand with the Velcro strips provided, in order to minimise the risk of anyone tripping over the power cord.
- If you carry the cooler along with its stand, please ensure that you hold on to both the cooler as well as the stand, as they are not attached to each other. Pregnant women should not – in the commercial area must not – carry the cooler and/or the stand.

2.3 Safety instructions for battery and battery charger

This device can be operated on a battery or on mains power.



Please observe the following safety instructions in order to avoid dangerous situations:

- Make sure that the battery does not get overheated. Keep it away from open fireplaces, heaters or radiators and do not leave the battery in the hot sun (e.g. in a locked car).
- Do NOT drop the battery and protect it from any hard shocks or blows.
- Do NOT allow the battery to get wet.
- Do NOT touch the battery charger or any of the plugs or electrical connections with wet hands.
- If you notice any damage to the plugs or the power cable, do NOT switch on the device, and contact our service department immediately so that the damaged part can be repaired or replaced.
- Do NOT open the device, as parts in the interior of the device could be current-carrying. Changing the electrical or mechanical design of the device can result in severe electric shocks or device malfunctions.
- Do NOT submerge the device in water or any other fluid.
- The device is NOT dishwasher safe.
- Please ensure that the air vents are always free of any blockages. Do not cover the air vents because this may cause the build-up of heat and create a fire hazard.
- Do NOT insert any objects into the air vents. Contact with current-carrying parts in the interior of the device will lead to electric shock.
- Only use batteries manufactured by PrioVino GmbH. The use of third-party batteries constitutes a fire hazard and can also result in damage to the product.

3. Before use

3.1 Unpacking the device

- Take the device out of the outer carton and remove all accessories from the packaging material.




- Packaging material is not a toy. Please do NOT allow children to play with packaging materials to avoid the danger of suffocation.

- After unpacking, please check that the delivery is complete and without any visible damage. Please contact us immediately if you receive an incomplete or damaged delivery.
- Keep the outer carton and packaging materials in a safe place so that you can return the product to us in its original packaging, should this ever become necessary.

3.2 Parts and accessories included

- Cooler
- Stand
- Battery
- Battery charger with attached charging plug
- Power cord
- Velcro strips


3.3 Names of working parts



User interface



Battery charger



3.4 Correct placement of the device

The cooler can be placed on its stand or directly on any other suitable surface. It is important that all four supporting legs below the device lie within the holding ring of the cooler tray. This ensures that the device is securely anchored to the cooler tray by its own weight.



- Make sure that the device is placed on a firm, even and perfectly horizontal surface with sufficient load-bearing capacity.
- Do NOT place the device in a damp or wet environment, or close to open fireplaces or hearths.
- Make sure that the battery charger is not covered and ensure that there is enough space between the charger and other objects. If heat is allowed to build up around the battery charger, it could result in a fire hazard.

We would be happy to provide consultation about the correct placement of the device on ships, aircraft, or other non-stationary surfaces. Please contact us for more information.

3.5 Checking electrical connections

Before you connect the device to a mains power source, compare the voltage and frequency of the battery charger with that of the power source. In order to prevent damage or malfunctioning of the product, these values must match. The type plate on the battery charger displays the relevant specifications.

In addition, please note the following:

- The electrical outlet to which the battery charger is connected must be protected by a circuit breaker (minimum 10 A).
- The device may only be connected to a mains power source with the power cord included in your delivery. Do NOT plug the device into a multiple power outlet or power strip as this can lead to a fire hazard due to overload.
- Ensure that the power cord does not lie over or under a hot or sharp-edged surface.

3.6 Charging the battery

The battery should be fully charged before you first switch on the device. The battery should only be charged with the battery charger supplied with the device.

- To charge the battery, insert the charger plug of the battery charger into the battery.
- Use the power cord to connect the battery charger to the electrical outlet. This will cause the lower LED to light up red.
- The upper LED will flash green while the battery is charging and light constantly green once charging is complete.
- Disconnect the battery charger from mains power.

- Disconnect the battery charger from the battery.



- If the upper LED lights up red or begins to flash in red, this is an indication of a malfunction. Discontinue the charging process immediately by removing the power plug from the electrical outlet and then contact our service department.

4. Set-up and operation

This device can be powered by an exchangeable and rechargeable battery or by being plugged into a mains power source.

4.1 Inserting the battery

- Open the lid by pressing on the first 'O' in the company logo on the cooler lid.
- Insert the battery into the battery enclosure until it clicks into place and the blue lamp in the on/off button lights up.

4.2 Setting the desired temperature

- To switch the device on, press the on/off button until the blue temperature display lights up.
- To set the desired temperature, first press the set button. The display will begin to flash.
- Use the plus/minus buttons to set the temperature you require.
- Then press the set button once again to confirm the temperature setting. The display will stop flashing and your desired temperature will be indicated in the temperature display.
- Press the push-up pin downwards.
- Replace the cooler lid.
- Insert the wine bottle into the bottle chamber.

When the battery is down to ca. 25% of full capacity, a blue LED lights up behind the air vents. This low battery alert is a reminder to either change the battery or plug the device into mains power.

Turn the device off when it is not in use to avoid unnecessary power consumption or battery drain.

4.3 Removing the battery

- Open the lid by pressing the first 'O' in the company logo on the cooler lid.
- Switch off the device by pressing the on/off button.
- Press down lightly on the battery for it to be ejected.
- Press the push-up pin downwards.
- Replace the cooler lid.

4.4 Mains operation

- Make sure that the battery is still in the device before plugging the device into mains power (see section 4.1 Inserting the battery). Powering the device using mains power is not possible unless the battery is inside the device.
- Insert the charger plug of the battery charger into the corresponding socket underneath the cooler.
- Connect the battery charger to the power cord using the C8 plug.
- Now connect the battery charger with the electrical outlet using the power plug.
- The battery will be automatically recharged while the device is connected to a mains power source.
- Do not remove the battery without first disconnecting the device from mains power.

Turn the device off when it is not in use to avoid unnecessary power consumption or battery drain.

5. Cleaning instructions

To prevent damage to the device and to protect the exterior from scratches, we recommend regular cleaning and care. Before cleaning, please switch off the device, disconnect it from mains power and remove the battery.

Please follow the cleaning guidelines outlined below:

- Wipe the device with a soft, damp cloth. Make sure you dry the device thoroughly after cleaning.
- Do not use aggressive or abrasive cleaning products or solvents of any kind, such as petroleum.
- Ensure that no water or humidity gets into the interior of the device through the air vents while cleaning.

- We recommend wearing cloth gloves while handling the device, in order to protect the surface of the device from being scratched.



- Do NOT submerge the device in water or any other fluid.
- This device is NOT dishwasher safe.

6. Storage

When storing the device overnight, please make sure that the device has been disconnected from mains power before storing it in a safe and dry location. When storing for longer periods of time, please ensure that the device is kept in a safe, dry and dust-free location. Remove the battery before storing for longer periods and keep the battery in a safe, dry and cool place with a maximum temperature of no more than 30 °C.

7. Service and maintenance



Repairs or maintenance on this device should be carried out solely by PrioVino professionals. Improper repairs or maintenance can cause damage to the product and represent significant danger to the life and well-being of the user.

For your own safety and to avoid malfunctions in the device, only use original spare parts supplied by PrioVino GmbH.

When making your request for repairs or maintenance on the device, please include the product identification number. This number can be found at the bottom of the battery enclosure or on the original product packaging.

8. Disposal

In case of disposal of the device, dispose the device, the battery and the battery charger in accordance with local ordinances and regulations for the proper disposal of electrical and electronic equipment.

9. Technical information

Device	Electrical wine cooler
Model	Premier
Temperature range	5 °C – 20 °C
Temperature intervals	0.5 °C
Bottle opening	9.4 cm diameter
Height of cooler without stand	28.5 cm
Total height with stand	73.5 cm/93.5 cm
Total weight (without battery)	10.3 kg/11 kg
Battery charger input	220 – 240 V/50 – 60 Hz
Depending on the model:	
Mains adapter output	12 V/5 A
Battery charger output	12.3 V/4 A
Permissible environmental conditions for operating	5 °C – 40 °C 15% – 85% relative humidity (non-condensing)
Emission sound pressure level	<70 dB(A)

10. Declaration of conformity



The device complies with EC Directive 2006/42/EC and EU Directives 2011/65/EU and 2014/30/EU.

For details, refer to the complete declaration of conformity on page 14.

Manufacturer and service address

PrioVino GmbH
Eschenweg 21
72076 Tübingen

Phone: +49 7071 1473016
Fax: +49 7071 610982
Email: info@priosvino.com
Internet: www.priosvino.com

EC Declaration of conformity

According to EC Directive 2006/42/EC, Annex II 1. A

We hereby declare,

PrioVino GmbH, Eschenweg 21, 72076 Tübingen

that the device referred to as

Designation:	Wine cooler
Type:	Premier
Serial number:	as of PVP0002
Year of construction:	as of 2018

complies with EC Machinery Directive 2006/42/EC.

The device also complies with the following directives:

2014/30/EC

2011/65/EC

The following harmonised standards have been applied:

DIN EN 60335-1:2012-10 +

B1:2014-04 + B2:2014-11

DIN EN ISO 12100:2011-03 + B1:2013-08

DIN EN ISO 13732-1:2008-12

DIN EN ISO 13732-3:2008-12

DIN EN ISO 13857:2008-06

The following national or international standards (or parts/clauses thereof) and specifications have been applied:

DIN ISO/TR 14121-2:2013-02

Responsible for the assembly of the technical documents:

Moritz Ortwein, PrioVino GmbH, Eschenweg 21, 72076 Tübingen

Tübingen, 25.01.2018

Date



Moritz Ortwein, Technical Director

PrioVino GmbH
+49 7071 1473016
info@priosvino.com
www.priosvino.com

